

VERICOM[®]

USER MANUAL

RECHARGEABLE LED FLOODLIGHT 10W

- Powered by Li-Ion Battery
- DC 8.4V Input
- High power integrated LED
- 120° beam angle
- Polished, finished Aluminum Die-Cast Casing
- IP65 Weather Resistant
- Keeps same lumen output until battery depletion
- Overcharge and over discharge protection
- Operating Temperature:
Charging: 0° (-18°C) up to 104°F (40°C)
Working: -4°F (-20°C) up to 131°F (55°C)

- 1 Handle
- 2 Angle adjustment knob
- 3 Base mounting bracket
- 4 Stand with Magnetic Feet
- 5 ON/OFF Switch
- 6 Charging Socket



Notes:

- Use only the charger equipped with the product for safety
- Please use water protection cap on socket after charging completes
- Comes fully charged
- Do not use a modified or damaged charger
- Do not leave the light charging for longer than 24 hours
- Disassembling the light will void warranty
- Charge the product at a minimum of every six month

Charging LED Indicator:

- When charging, the LED indicator is red
- When fully charged, LED indicator turns green

Warning:

This device uses a rechargeable, Lithium-Ion battery that can rupture, ignite and cause serious injury if used improperly. Please remember the following safety rules:

- DO NOT place batteries and devices in fire or near high temperatures
 - DO NOT tamper with battery wiring
 - DO NOT puncture or damage the battery
 - DO NOT use batteries that appear damaged
 - DO NOT immerse or expose the batteries to water
 - DO NOT attempt to alter or modify battery
 - DO NOT attempt to change the batteries in any manner not described by the user manual
 - DO NOT dispose of the battery in fire or water
- Failure to heed these warnings may/can result in personal injury or property damage

WEEE-Reference of Disposal:


The symbol of the waste bin on wheels refers to the necessity of separate collection for this item. Please assist with environmental protection and ensure that this device is given to the proper waste system when disposing.



Batteries and accumulators are not to be disposed of in normal household trash containers. Product users are recommended to dispose of batteries and accumulators, whether or not they contain harmful substances, to a certified waste disposal facility so they can be handled in an environmentally friendly manner. In addition, these products must be completely discharged prior to disposal.



Batteries and rechargeable batteries need to be removed from their housings and disposed of separate from household trash. Consumers are recommended to bring all batteries to a proper waste disposal organization to be handled appropriately.



Warranty:

For a period of 1 year from the date of purchase, our company will repair or replace this product without charge, as long as the guidelines for use as detailed in this manual are followed. If this product fails due to a defect in material or workmanship under normal operating conditions, a replacement or repair will be offered.

